

Application note: How to switch a MorphoAccess™ to standalone mode.

Factory settings enable the MorphoAccess™ to operate in connected mode with a MorphoAccess™ Management System (MMS).

To switch the MorphoAccess™ to standalone mode, a simple configuration change is needed in the System Menu.

Note: This operation will only work with MorphoAccess™ 200 and 200 S, which have standalone capabilities. MorphoAccess™ 300S does not have standalone capabilities.

First, go to the **Administration Menu** pressing the key sequence <#> <*> <#>.

Press PIN for password administrator identification.

Enter the factory password 12345.

Go to the **System Menu** pressing ASYSSTE.

Enter the factory password 12345.

Change your configuration pressing CONFIG.

Go to file */cfg/Maccess* using NEXT and PREV. Press EDIT.

Go to section *Admin* using NEXT and PREV. Press EDIT.

Select the key *standalone* using NEXT and PREV.

To change the key value press EDIT. To enable standalone mode, the key must be set to **1**.

When desired value is set, press OK. The value of the key should be updated.

When done, go back to the **System Menu** pressing EXIT three times.

Quit the **System Menu** pressing EXIT.

Press MACCES to launch the application.

Congratulations! Your MorphoAccess™ is now ready to operate in standalone mode.